



USB Charger
USB-зарядное устройство

3 Gang Earthed-With Switch-USB Charger
Колodka с/з 3 входа с выключателем с USB разъемом

721 0300 302U

Outbox/Коробка: 36 pcs/шт
7,37 kg / 0,0383м3

3 Gang Earthed-With Switch-USB Charger-Cable(3x1mm2)
Удлинитель с/з 3 входа с выключателем с USB разъемом (3*1mm2)

721 0302 302U - 2m (5,25kg/0,0236м3)
721 0303 302U - 3m (6,60kg/0,0241м3)
721 0305 302U -5m (8,28kg/0,0247м3)
721 0307 302U -7m (10,26kg/0,0245м3)
721 0310 302U -10m (13,15kg/0,0215м3)

Outbox/Коробка: 12 pcs/шт



4 Gang Earthed
Колodka с/з 4 входа

721 0400 401

Outbox/Коробка: 36 pcs/шт
5,90 kg / 0,0300м3

4 Gang Earthed-Cable(3x1mm2)
Удлинитель с/з 4 входа (3*1mm2)

721 0402 401 - 2m (4,69kg/0,0186м3)
721 0403 401 - 3m (5,60kg/0,0186м3)
721 0405 401 - 5m (7,70kg/0,0239м3)
721 0407 401 -7m (9,35kg/0,0225м3)
721 0410 401 -10m (12,60kg/0,0206м3)

Outbox/Коробка: 12 pcs/шт

4 Gang Earthed-With Switch
Колodka с/з 4 входа с выключателем

721 0400 402

Outbox/Коробка: 36 pcs/шт
5,83 kg / 0,0264м3

4 Gang Earthed-With Switch-Cable(3x1mm2)
Удлинитель с/з 4 входа с выключателем (3*1mm2)

721 0402 402 - 2m (5,10kg/0,0221м3)
721 0403 402 - 3m (6,50kg/0,0221м3)
721 0405 402 - 5m (8,10kg/0,0239м3)
721 0407 402 -7m (10,10kg/0,0225м3)
721 0410 402 -10m (12,93kg/0,0208м3)

Outbox/Коробка: 12 pcs/шт

