

Инструкция по сбросу пароля на камерах серии Lite P6S

1. Скачайте ПО EasySearch по ссылке https://storage.yandexcloud.net/firmwarest/EasySearch_v1.0.1.6542.rar и установите его
2. Откройте программу после установки и выберите из списка камеру которой нужно сбросить пароль и отметьте ее галочкой
3. Выберите справа опцию Forget Password. После чего программа выдаст вам два QR кода. Один для скачивания мобильного приложения Hieasy, а второй для получения временного пароля.

The screenshot shows the EasySearch software interface. At the top, there are checkboxes for DVR, NVR, IPC, and IPD, and a 'Retype password' checkbox. Below this is a table of cameras with columns for Id, IP(sort), Device type, MAC, Version, and UID. Row 5 is highlighted with a red box, indicating it is selected. To the right of the table are network settings for the local network interface, including interface type, IP address, subnet mask, and gateway. Below the network settings is a 'Forget Password' dialog box. This dialog box has two tabs: 'Retrieve password' and 'Modify password'. The 'Retrieve password' tab is active and shows two QR codes. The first QR code is for downloading the application, and the second is for retrieving the temporary password. Below the QR codes are instructions: 'Scan the QR code above to download the mobile app' and 'Please use the mobile app to scan the QR code above to get the temporary password.' The 'Modify password' tab is also visible, showing fields for 'Temporary password', 'New password', and 'Confirm password', along with 'Modify' and 'Cancel' buttons. A red box highlights the 'Forget password' button in the background interface.

Id	IP(sort)	Device type	MAC	Version	UID
<input type="checkbox"/>	192.168.1.87	F8/IPG-9280PGS-AI	5A:5A:00:C3:C4:9A	1.5.0-20220831SG-HF	IOTEAA-786218-TUWZM
<input type="checkbox"/>	192.168.1.60	F4G	5A:5A:00:5E:4C:D9	2.7.0-20241112SG-HF	IOTEAA-257242-BHDZB
<input type="checkbox"/>	192.168.1.4	F4G	5A:5A:00:47:F1:9E	2.7.0-20230727SG-HF	IOTEAA-253299-XFFVN
<input type="checkbox"/>	192.168.1.3	F5G	5A:5A:00:5E:50:61	3.7.1-20230531SG-HF	IOTEAA-241428-PWYSG
<input checked="" type="checkbox"/>	192.168.1.149	F4G	5A:5A:00:4D:44:9A	2.7.0-20241203SG-HF	
<input type="checkbox"/>	192.168.1.126	H8SX-50PSD	5A:5A:00:CA:70:CF	1.0.0-20250624SG	IOTFBB-383050-TDUKN
<input type="checkbox"/>	192.168.1.86	F4G	5A:5A:00:AB:53:19	2.7.0-20230727SG-HF	
<input type="checkbox"/>	192.168.1.8	T5AI/IPG-5950PCS...	5A:5A:00:C7:20:13	3.0.1-20250514	IOTFBB-539882-LJZYP
<input type="checkbox"/>	192.168.1.101	N316B-11NEA-AI-Z...	5A:5A:00:7E:74:6F	6.8.1-20250821	

4. Скачайте и установите мобильное приложение Hieasy
5. После установки и входа в учетную запись нажмите «+» в верхнем правом углу и отсканируйте QR код «Retrieve password» в программе EasySearch
6. В ответ в мобильном приложении вам отобразится временный пароль. Введите его в поле Temporary Password
7. Далее в следующих двух вкладках придумайте и подтвердите новый пароль, который должен соответствовать следующим требованиям –
 - 1) Пароль должен состоять из латинских букв и цифр
 - 2) Хотя бы одна заглавная буква
8. После чего с новым паролем вы можете спокойно заходить в настройки своей камеры и пользоваться всем функционалом