

FROM THE FOUNDER OF THE #VIKISEWS BRAND




Back in 2016, when I was working on my first set of sewing instructions, I was trying to write them in such a way that even a complete beginner could easily understand and use them to create their very first garment. These instructions laid the foundation for the Vikisews brand, its vision and its mission. I wanted to create modern patterns with the utmost detailed and clear instructions.

Now, with each new collection we are constantly improving our instructions, amending them and adding more relevant details. By the time the final product reaches you, our drafters, correctors, and editors would have spent weeks perfecting every word and every photograph. If you compile a few of our instructions together, you will get a sewing manual that will assist you in sewing all kinds of garments at any difficulty level.


And I would be very happy if these instructions helped you to turn your hobby into a lifelong passion... Enjoy the process! Create your ultimate dream wardrobe! Wear your garments proudly for years to come!

If you have any questions, please contact us at info@vikisews.com — we are always there to help.



DIA PATTERN DESCRIPTION

Dia is a straight-cut, semi-fitted cami top with adjustable straps. The front features bust darts and a V-shaped neckline with a lace insert. The top is hip-length.



IMPORTANT!

The contents of this pattern are copyright protected and belong exclusively to Vikisews. You may use Vikisews patterns for personal use. It is prohibited to share Vikisews patterns and instructions with third parties, as well as to publish patterns and instructions online for public access. **Non-compliance with the mentioned rules is a violation of the US copyright law and may result in civil liability and criminal prosecution.**

You may use Vikisews patterns for commercial use, to sew custom-made garments and/or create fashion collections, on the condition that the patterns are solely used in a manufacturing setting and are not further shared with individuals.

TOTAL EASE ALLOWANCE

	Bust ease	Waistline ease	Hipline ease
cm	6.3–8.1	30–31.4	8–9.2
inches	2 1/2–3 1/4	11 3/4–12 3/8	3 1/8–3 5/8

GARMENT LENGTH

Height, cm	Back length from waist down, cm	Height, ft	Back length from waist down, in
1 (154–160)	23	1 (5'1"–5'3")	9
2 (162–168)	24	2 (5'4"–5'6")	9 1/2
3 (170–176)	25	3 (5'7"–5'9")	9 7/8
4 (178–184)	26	4 (5'10"–6'1")	10 1/4

SUGGESTED FABRIC

To sew this top, choose dress-weight fabrics with the following properties:


- medium weight, soft, non-stretch, opaque
- the fiber content can include natural fibers (silk), artificial fibers (viscose), blends (silk + polyester, silk + viscose, etc.), and synthetics (polyester)
- the following fabrics are recommended: artificial silk, natural silk, satin, modal.

Attention! We do not recommend heavyweight structured fabrics and lightweight sheer fabrics.


The top in the photo is made of artificial silk. The fabric is soft, with some bounce, non-structured, and double-sided. The fiber content is 100% polyester. The fabric weight is 190 g/m².



Press the dart flat.



Press the dart upwards, shrink out the fullness at the dart point.



Place the two front neckline insert pieces right sides together. Align the center seam edges (the angled ones), match the notches, and pin. Machine-stitch, backstitching at the beginning and end of the seam.